

Using your DVD-963SA **Modified SACD Player**

The quality of sound from your upgraded Philips DVD-963SA SACD/DVD player is far better than that of the stock unit. In order to receive the best possible sound from your unit a few guidelines must be addressed.

- **Burn-in:** The unit must be allowed **at least 150 hours** of playing time to “burn in” before optimum sound quality will be achieved. Your upgraded unit has already been running for 24 hours before it was returned to you. Please allow the unit time to burn in before making any subjective observations.
- **Cables:** The quality of your interconnect cables can also have a major effect on the sound quality. The use of low-quality interconnect cables can seriously hinder the sound that modification accomplishes. If the unit doesn’t sound right, then try different interconnects. There are many excellent cables available, and the best way to choose one is by in home audition.
- **Operation:** The multichannel-front output on the back of the player is disabled. The new RCA’s should be used for both Multichannel and Stereo operation.
Note: The top of the player feels warm. This is normal.

If you have any problems with the mods feel free to contact me immediately through my website: www.SACDmods.com All modifications are warranted from defects for 1 year from the date of installation.*

* Not responsible for damage due to electrical surges or lightning damage. Not responsible for customer negligence. Operation of this unit must be conducted in the same manner as described in the Philips owner’s manual. Modifying this player does void your manufacturer warranty. This warranty does not cover failures or defects in Philips components unless I can confirm it was caused by the modifications. **We service what we sell!**